

Operating Manual
Quattrino
 RE529, two tone

We congratulate you on your new Pager from the RE529 family. You now have a device which dominates with its performance, equipment and operational safety. Despite the simple handling of the unit, we would recommend that you read through the operating manual thoroughly. We are sure that you will find a true and reliable companion in your pager.

Contents

1	Putting Into Operation	2
1.1	Power Supply	2
1.2	Inserting the Battery	2
1.3	Automatic Switch-On.....	2
1.4	Switching Off	2
1.5	Switching On / Keys	3
1.6	Selecting the Operating Status.....	3
2	The complete LC Display of your unit.....	4
2.1	Acoustic ON	4
2.2	Mini-Beep	4
2.3	Acoustic OFF	4
2.4	Monitor	4
2.5	Volume	5
2.6	Field Strength Alarm	5
2.7	Address Display, Profiles	5
2.8	Choosing Profiles	5
2.9	Message (Memo only).....	5
2.10	Battery Status Indicator	6
2.11	Battery / Accumulator Recognition	6
2.12	New Message.....	6
2.13	Call Signalling.....	6
2.14	Call Retrieving / Deletion.....	6
3	General	7
3.1	Battery Life - Week Battery	7
3.2	Illumination	7
3.3	Accessories.....	7
3.4	Customer Service.....	7



WARNING- Do not operate this product in hazardous atmosphere or explosion risk areas!

- Do not open device or remove labels!

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) This device must accept any interference received, including interference that may cause undesired operation.



WARNING- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.