

# Operating Manual RE429NT+

## Quattrino tone, eco, voice, memo

We congratulate you on your new Pager from the RE429 family. You now have a device which dominates with its performance, equipment and operational safety. Despite the simple handling of the unit, we would recommend that you read through the operating manual thoroughly. We are sure that you will find a true and reliable companion in your Pager.

### Contents

1	Introduction.....	2
2	Putting into operation.....	2
	2.1 Power supply.....	2
	2.2 Inserting the battery.....	2
	2.3 Automatic switch-on.....	2
	2.4 Switching off.....	3
	2.5 Switching on.....	3
	2.6 Selecting the operating status.....	3
3	The complete LCD Displays.....	4
	3.1 Quattrino voice, memo.....	4
	3.2 Quattrino tone,eco.....	4
	3.3 Acoustic ON.....	5
	3.4 Mini-beep.....	5
	3.5 Acoustic OFF.....	5
	3.6 Monitor.....	5
	3.7 Volume.....	5
	3.8 Field strength alarm.....	5
	3.9 Address display.....	6
	3.10 Switching ON and OFF of the activated addresses.....	6
	3.11 Message.....	6
	3.12 Battery status indicator.....	6
	3.13 Battery / accumulator recognition.....	6
	3.14 New message.....	7
	3.15 Call retrieving.....	7
	3.16 Call signalling.....	7
	3.17 Alarm timer.....	7
	3.18 Acknowledgement / deletion.....	8
4	General.....	8
	4.1 Battery operational life.....	8
	4.2 Week battery.....	8
	4.3 Illumination.....	8
	4.4 Accessories.....	8
	4.5 Customer service.....	8